

NETVOX™ PAGERS



NETVOX G100

4 LINE ALPHANUMERIC FLEX™ PAGER

Thank you for choosing the NETVOX G100.

Tomvic Industries Ltd

Authorised Distributor of Netvox Pagers

PO Box 34634

13 Sunnyhaven Ave

Beach Haven Village

Auckland

Ph: (09) 481 9020

Fax: (09) 481 9029

Email: info@tomvic.co.nz

Web: www.tomvic.co.nz

Getting Started

Pager Features:

- 4 line, 20 characters per line
- Up to 30 personal message slots
- Notebook - stores up to 99 messages
- 5 alarm clocks
- Silent beep, vibrate and 26 user selectable alerts
- GPS Update - time and date updated by network
- Auto on/off at selectable times
- Backlight

Function Buttons



Pager On:

Place one AAA alkaline battery into back of pager. Pager will alert. Press \rightarrow to stop alert.

Pager Off:

- Press \bullet button
- Select 'turn pager off' using f or ,,
- Press \rightarrow button to turn pager off
- Press and hold \bullet to turn pager back on

Message Icons




Alert Settings

- Press \bullet to enter the function menu screen from the status screen
- Press f or ,, to move through function menu icons until audible alert, silent alert (vibrate) or silent beep (vibrate and beep) appears
- Audible alert; press \rightarrow to enter alert options. Use f or ,, to scroll through alert options. Press \rightarrow to select alert.
- Silent alert/silent beep; press \rightarrow to confirm alert

Time and date

- Press \bullet to enter function menu screen from the status screen
- Press f or ,, to move to 'set time/date'
- Press \rightarrow to enter 'set time/date' option
- Press ,, to move through hours/minutes and date
- Press f to adjust settings
- Press \rightarrow to confirm setting

Status Screen:



1. Number of Personal Messages
2. Signal Indicator
3. Coverage Indicator
4. Alert Mode Indicator
5. Low Battery Alert
6. N/A in NZ
7. Alarm Indicator
8. Automatic On / Off Indicator
9. Time Display
10. Continuous Message Indicator
11. Day of Week Indicator

Function Menu

- Press \bullet to enter the function menu screen from the status screen
- Press f or ,, to move through function menu icons
- Press \rightarrow to enter the current selected function sub-menu (function setting mode)

Alarm Setting (5 alarms)

- Press \bullet to enter function menu screen from the status screen
- Press f or ,, to move to 'set alarm'
- Press \rightarrow to enter 'set alarm' option
- Press \rightarrow again to change settings
- Use ,, to move through hours/minutes and f to change setting
- Press \rightarrow to confirm alarm setting/s

Reading a message

When a message is received your pager will alert. Press **↵** to read the new message.

If message is longer than one screen press **↵** until message is read.

Press **f** or **„** to skip through messages.

Set Auto On/Off Function

- Press **●** to enter the function menu screen from the status screen
- Press **f** or **„** to move to 'set auto on/off'
- Press **↵** to enter 'set auto on/off' option
- Use **„** to move through hours/minutes
- Press **f** to change setting
- Press **↵** to confirm setting

⊕ On
⊖ Off

Backlight

- Press **●** and **↵** buttons at the same time to turn on backlight
- Repeat the same steps to turn backlight off

Service and Repair

Complete the warranty form enclosed in pager box.

Contact your Paging Dealer or Tomvic Industries Ltd for enquiries for servicing your pager.

TOMVIC INDUSTRIES LTD

PO Box 34634
Birkenhead
Auckland
New Zealand

Ph: (09) 481 9020 Fax: (09) 481 9029
info@tomvic.co.nz
www.tomvic.co.nz

Saving a Message

When 30 messages have been received in the Personal Message Area the next personal message will overwrite the oldest message. Therefore, it is important to save messages that you do not want to be overwritten.

- Display message on the screen
- Press **●** to enter the message function menu
- Press **f** or **„** to move to 'protect message'
- Press **↵** to confirm

Repeat steps above to unprotect message. Choose 'unprotect message' from the message function menu.

Deleting a Message or All Messages

- Display message on the screen
- Press **●** to enter the message function menu
- Press **f** or **„** to move to 'delete message'/'delete all'
- Press **↵** to confirm

Group Messaging Function (this function separates group messages from the personal message area. The function has to be programmed into the pager - contact your Dealer or Tomvic Industries Ltd)

- Press **●** to enter the function menu screen from the status screen
- Press **f** or **„** to move to 'mailbox'
- Press **↵** to enter mailbox area
- Press **f** or **„** to select mailbox
- Press **↵** to read mailbox message
- Press **f** or **„** to select message within mailbox

Netvox G100 Paging Accessories

Give your pager added protection and security with the range of PagerMate® accessories.



A large selection of pager pouches are available. These all provide added protection for the pager screen and are splash proof.

For added security PagerMate® has a large range of chains and bungee cords to ensure you won't lose your pager while on the move.



Saving a Message in Notebook Area

- Display message on screen
- Press **●** to enter the message function menu
- Press **f** or **„** to move to 'save to note'
- Press **↵** to confirm

To Read Message in Notebook Area

- Press **●** to enter the function menu screen from the status screen
- Press **f** or **„** to move to 'personal note'
- Press **↵** to read messages
- Press **f** or **„** to move through messages

To install or replace battery

- Place the pager face down in the palm of your hand
- Release sliding latch and push sideways with a click to unlock the battery cover, slide battery cover along and out
- When replacing batteries turn pager off, remove old battery and replace with new battery. Check polarity is correct
- Place cover on track and move along until cover clicks in place. Push down sliding latch.

ALWAYS USE AN ALKALINE BATTERY

PagerMate® Wireless Messaging Software

PagerMate® has a range of software available to suit all your business needs from standalone PCs to larger server environments. The software is reliable, feature-rich and designed for end users who require alphanumeric (text) paging capabilities from a PC or Laptop. The software enables you to send messages to text enabled mobile phones as well as pagers, providing you with an efficient and effective way of communicating to people on the move.

- **Wireless Office Express** - Entry Level Software
- **Wireless Office** - Ability to schedule future messages
- **Wireless Pro** - Selectively forward emails to pagers or phones
- **WordTrek Plus** - Portable unit with built in modem & software

Server software available upon request.
Distributed by Tomvic Industries Ltd.